








Assembly instruction

- S1**  25mm 16pcs
S2  20 mm 8pcs
S3  10mm 8pcs
S4  2pcs
S5  2pcs

Screw detail




A= cage front





B= cage back


1 S1*8pcs;
B*1pc;C*2pcs




2 S1*8pcs;
H*1pc



C=cage side




D= samll door






F= rainproof drawer&stair

3 S2*2pcs;
F1/F2*1pc




4 S2*4pcs ; G1*2pcs;G2*1pc



S2 step 4 to strong

G= rainproof roof&top

S2*2pcs;S3*8pcs;S4*2pcs
A/D1/D2



H= finished cage front

SOFTLY REMIND

Make sure screws are accurately inserted. Avoid the points of nails sticking into the living space of your pet; they could cause injury.

SOFTLY REMIND

Fir&plywoode sections may twist when unassembled, if you happen to meet this problem do two steps as follow:

- 1.find out which surface is curved.
- 2.put the curved face down-ward the floor for a shart time under the sunshine (if no sunshine,thime should meed little more).
- 3.then you can find the fir&plywoode revert to level.

thank you